

Technical Data Sheet

Anti-static agent for solvent

- Eliminates electrostatic charge build up
- Makes ironing easier
- Suitable for both natural and synthetic textiles
- Does not create foam into the distillation unit

Tintostatic



Technical Data Sheet

Method of use: Tintostatic is used with machine fully loaded, during the second bath, either by manually dosing the button trap or with an automatic dosing unit

Dosage:

Continuous distillation: 8 – 10 ml of Tintostatic per kg of dry garments

Manual distillation: 10 ml of Tintostatic per kg of dry garment during the first wash with clean perchloroethylene. 3 ml per kg of dry garments during the subsequent washes without distillation.

Must not be used in any pre-brushing applications

Ionicity : Cationic

Tintostatic

