

Technical Data Sheet

Hygienising oxygen based bleach for laundry.

Balanced hydrogen peroxide, paracetic acid and acetic acid mix.

- Active from 30°C
- With recommended dosage respects colours and textiles
- Ideal for washing very dirty linen
- Hygienises even at low temperatures

Hygienclean



Technical Data Sheet

Method of use: HygienClean is used with standard detergent during the main wash at 40 - 60°C .

Dosage : 5 – 10 ml per kg of dry garments with machine fully loaded, according to the degree of soiling and the textile type.

DO NOT MIX WITH CHLORINE BASED BLEACHES DURING THE SAME BATH

Technical features:

Aspect = limpid liquid
Smell = pungent
pH 1% = 2,0 – 3,0
Density at 20°C = 1,100 - 1,150g/ml

Composition: peracetic acid, acetic acid,
hydrogen peroxide, stabilizer

HygienClean

